



The "K4 Compact" with water-cooled motor is ideal for occasional removal of moderate dirt. This high-pressure cleaner is ideal for garden fences, bicycles and small vehicles. This machine is compact and powerful. Two handles and a practical telescopic handle make the machine easy to transport. It is also easy to store. Further impressive features include: Quick Connect gun, 6 m high-pressure hose, Vario Power spray lance (VPS) with practical twist action pressure regulation, dirt blaster with rotating pencil jet for removing stubborn dirt and reliable water filter for pump protection.





K 4 Compact

- Quick Connect: The high-pressure hose is easy to manoeuvre, clicking quickly in and out of the device and trigger gun
- Equipment includes an integrated suction mechanism for detergents

Technical data

Order No.		1.637-311.0
EAN code		4039784729384
Pressure	bar / MPa	20-130 / 2-13
Flow rate	l/h	420
Max. inlet temperature	°C	max. 40
Connection load	kW	1.8
Weight without accessories	kg	10.7
Dimensions (L × W × H)	mm	516 × 295 × 282

Equipment

High-pressure gun	Standard Quick Connect
Vario Power Jet	■
Dirt blaster	■
High-pressure hose	m 6
Quick Connect on the side of the device	■
Detergent application via	Suction
Telescopic handle	■
Water-cooled motor	■
Integrated water filter	■
A3/4" garden hose connector adaptor	■

■ Included in delivery.

ACCESSORIES FOR K 4 COMPACT

1.637-311.0

KÄRCHER


		Order No.						Price	Description	
Miscellaneous										
G 180 Q, Trigger gun Quick Connect	1	2.642-889.0							The new G 180 Q trigger gun, equipped with Quick Connect, is 13 cm longer and offers even more convenience and ergonomics for cleaning with Kärcher pressure washers.	■
Water filter	2	4.730-059.0							Water filter to protect the pressure washer pump against small dirt particles from impure water.	□
O-ring set	3	2.640-729.0							Replacement O-ring set for easy replacement of O-rings and safety plugs on pressure washer accessories.	□
Garden hose adaptor	4	2.640-732.0							Adaptor for garden hose connector for attaching all Kärcher brushes and cleaning sponges directly to garden hoses with quick-coupling system.	□
High-pressure replacement hose: With anti-twist system and Quick Connect system										
H 10 Q, PremiumFlex Anti-Twist	5	2.643-585.0							Innovative PremiumFlex high-pressure hose with anti-twist system for kink-free work. 10 m long. Includes Quick Connect adaptor. For devices in the K 2-K 7 ranges.	□
High-pressure replacement hose: system from 2009 with Quick Connect system										
H 9 Q, High-Pressure Hose Quick Connect	6	2.641-721.0							For devices in the K 2 - K 7 ranges with Quick Connect. For Kärcher Consumer pressure washers from 2009 or later, on which the hose is attached to the trigger gun and device with quick coupling. 9 m, 180 bar, 60°C.	□
High-pressure hose extension system from 2008 for devices with Quick Connect system										
XH 10 Q, Extension Hose Quick Connect	7	2.641-710.0							High-pressure hose extension for increased flexibility. 10 m robust DN 8 quality hose for long durability. For K 3 - K 7 devices manufactured in 2008 or later with Quick Connect connection and for some K 2 devices manufactured since 2010 with Quick Connect connection. Connect between trigger gun and high-pressure hose.	□
XH 6 Q, Extension Hose Quick Connect	8	2.641-709.0							High-pressure hose extension for greater flexibility. High-quality, robust 6 m DN-8 quality hose for long durability. For K 3 - K 7 devices manufactured since 2008 and for some K 2 devices manufactured since 2010 with Quick Connect adaptor. Connects between the spray gun and pressure hose.	□
XH 10 QR, Extension Hose, Quick Connect Rubber	9	2.641-708.0							High-pressure rubber hose extension for increased flexibility. 10 m high-quality hose with steel reinforcement for long durability. For K 3 - K 7 devices manufactured after 2008 with Quick Connect adaptor and a Better or Best trigger gun. Connect between trigger gun and high-pressure hose.	□
Connectors/Tap adaptors										
Universal Hose Connector with Aqua Stop	10	2.645-192.0							Universal hose connector with Aqua Stop in ergonomic design for comfortable handling.	□
Universal Hose Connector	11	2.645-191.0							Universal hose connector in ergonomic design for comfortable handling.	□
Hoses										
Hose set for pressure washers	12	2.645-156.0							Hose set for high-pressure cleaning and garden watering. With 10 m PrimoFlex® hose (3/4"), G3/4 tap adaptor, universal hose connector and universal connector with Aqua Stop.	□
Water supply hose set	13	2.645-258.0							Hose set for high-pressure cleaning and garden watering. With 10 m PrimoFlex® hose (1/2"), tap adaptor, universal hose connector and universal connector with Aqua Stop.	□

■ Included in delivery. □ Available accessories.

ACCESSORIES FOR K 4 COMPACT

1.637-311.0

KÄRCHER



		Order No.					Price	Description	
PrimoFlex® hose – 1/2" 20 m	14	2.645-138.0						Extra robust and kink-resistant PrimoFlex® quality garden hose (1/2"). 20 m in length. With pressure-resistant, woven reinforcement. Non-hazardous to health. Bursting pressure: 24 bar. High temperature resistance from –20 to +65°C	<input type="checkbox"/>
Hose storage and hose trolley									
Hose trolley HT 3.420 Kit 5/8"	15	2.645-167.0						Fully assembled hose trolley with height-adjustable handle, angled hose connection, freewheeling crank handle and sophisticated folding function for space-saving storage.	<input type="checkbox"/>
Premium Hose Reel HR 7.315 Kit 1/2"	16	2.645-164.0						Fully equipped watering station. With detachable hose reel, storage for nozzles and sprinklers, large storage box and fixing option for spray lances.	<input type="checkbox"/>
High-Pressure replacement hose kit system from 1992									
HK 12, High Pressure Hose Kit	17	2.643-909.0						Accessory kit with 12 m high-pressure hose, high-pressure gun for K 2 – K 7 ranges and adaptor for retrofitting the practical Quick Connect system. Fits all Kärcher Consumer pressure washers manufactured since 1992. Not for hose reel devices.	<input type="checkbox"/>
HK 7.5, High Pressure Hose Kit	18	2.643-910.0						Accessory kit with 7.5 m high-pressure hose, high-pressure gun for K 2 – K 7 ranges and adaptor for retrofitting the practical Quick Connect system. Fits all Kärcher Consumer pressure washers manufactured since 1992. Not for hose reel devices.	<input type="checkbox"/>
Extension Hose Adaptor Set	19	2.643-037.0						2-part adaptor set for the connection of an extension hose with screw thread to a pressure washer with Quick Connect system.	<input type="checkbox"/>
HK 7.5, High-Pressure Hose Kit	20	2.641-828.0						Accessory kit with 7.5 m high-pressure hose, high-pressure gun for K 2 – K 7 ranges and adaptor for retrofitting the practical Quick Connect system. Fits all Kärcher Consumer pressure washers manufactured since 1992. Not for hose reel machines.	<input type="checkbox"/>
HK 12, High-Pressure Hose Kit	21	2.642-953.0						Accessory kit with 12 m high-pressure hose, high-pressure gun for K 2 – K 7 ranges and adaptor for retrofitting the practical Quick Connect system. Fits all Kärcher Consumer pressure washers manufactured since 1992. Not for hose reel machines.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

ACCESSORIES FOR K 4 COMPACT


1.637-311.0

KÄRCHER



		Order No.						Price	Description	
Hard surface cleaners										
PS 40, Power Scrubber Surface Cleaner	1	2.643-245.0							PS 40 power scrubber with three integrated high-pressure nozzles. Powerful cleaning action removes stubborn dirt from surfaces quickly and easily. Ideal for stairs and edges.	<input type="checkbox"/>
T 550, T-Racer Surface Cleaner	2	2.643-251.0							T-Racer Surface Cleaner T 550 for splash-free cleaning of large surfaces. With detergent application system, power nozzle for corners/edges, protection grid for gravel surfaces, pressure adjustment and handle.	<input type="checkbox"/>
T 450, T-Racer Surface Cleaner	3	2.643-214.0							Cleans large surfaces without splashing: T-Racer Surface Cleaner T 450. Extra power nozzle for corners and edges, handle for vertical cleaning, protection grid for gravel surfaces, cleaning pressure adjustment.	<input type="checkbox"/>
T 350, T-Racer Surface Cleaner	4	2.643-252.0							With the T-Racer Surface Cleaner T 350, large surfaces can be cleaned without splashing. Continuous pressure adjustment for hard and sensitive surfaces. Handle for vertical cleaning.	<input type="checkbox"/>
Replacement Nozzles Accessories	5	2.643-338.0							High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.	<input type="checkbox"/>
Replacement Nozzles Accessories T 350	6	2.643-335.0							The high-quality replacement nozzles guarantee easy replacement of nozzles and are suitable for the T-Racer T 300 / T 350 surface cleaners for the pressure washer unit classes K 2 to K 7.	<input type="checkbox"/>
T-Racer T 250 Surface Cleaner	7	2.642-194.0							T 250 T-Racer for spray-free surface cleaning. With extra handle for cleaning vertical surfaces. The accessories are suitable for Kärcher Home&Garden pressure washers, classes K 2 - K 7.	<input type="checkbox"/>
Brushes										
WB 150, Power Brush	8	2.643-237.0							WB 150 power brush for splash-free cleaning of sensitive surfaces. The effective combination of high pressure and manual brush pressure saves energy, water and up to 30% time.	<input type="checkbox"/>
WB 100, Rotating Wash Brush	9	2.643-236.0							Rotating washing brush with joint for cleaning all smooth surfaces, e.g. paint, glass or plastic. 18° infinitely adjustable joint on handle for cleaning difficult to reach areas.	<input type="checkbox"/>
WB 60, Soft Surface Wash Brush	10	2.643-233.0							Soft brush for cleaning large areas, e.g. cars, caravans, boats, conservatories or roller shutters. Working width of 248 mm ensures good coverage.	<input type="checkbox"/>
Wheel washing brush	11	2.643-234.0							Wheel wash brush for effective cleaning also in difficult to reach areas. Uniform 360° water distribution for a perfect cleaning result.	<input type="checkbox"/>
Soft Wash Brush WB 50	12	2.643-246.0							Universal soft brush for cleaning all types of surfaces. With soft brushes, outer protector ring, union nut and rubber pad.	<input type="checkbox"/>
Spray lances										
Splash Guard	13	2.642-706.0							Transparent splash guard for Class K 2 to K 7 Kärcher pressure washers protects the operator and surrounding area from spray water. Ideal for cleaning corners and edges.	<input type="checkbox"/>
Angled Spray Lance	14	2.638-817.0							Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	<input type="checkbox"/>
1-step lance extension	15	2.643-240.0							Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

KÄRCHER

< 4 Compact, 1.637-311.0, 2017-04-26

ACCESSORIES FOR K 4 COMPACT

1.637-311.0



		Order No.					Price	Description	
Sand and wet-blasting kit	34	2.638-792.0						Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.